


400L 3-Point Spreader



400L 3-Point Spreader

PART#	Description	QTY
1	Frame	1
2	Bolt, Hex Head M10x20,Zinc	2
3	Washer,Flat,10mm, Zinc	5
4	Hair Pin	4
5	Rod, Flow Adjustment	1
6	Lever, Adjustment	1
7	Spring, Pressure	1
8	Bolt, Hex Head M10x70,Zinc	1
9	Handle, Rubber, 8x20	1
10	Brace, Left	1
11	Nut,Hex M10, Zinc	14
12	Washer,Lock,10mm, Zinc	10
13	Rod,Selector, RX-LX	1
14	Pin, Connection, ø8*16	1
15	Agitator	1
16	Bolt, Hex Head M8x45, Zinc	1
17	Lock Nut,M8	1
18	Washer, Nylon, 25mm	1
19	Bolt, Carridge,M10x25, Zinc	5
20	Bar, Hopper Reinforcement	1
21	Washer,Flat,10.5mm, Zinc	1
22	Hopper	1
23	Retainer Bushing	1
24	Hopper Support Pan	1
25	Bolt, Carridge,M8x25, Zinc	6
26	Washer,Flat,8mm, Zinc	14
27	Washer,Lock,8mm, Zinc	14
28	Nut,Hex M8, Zinc	15
29	Seed Disc, Upper(2 holes)	1
30	Distribution Disc,Lower (3 holes)	1
31	Bolt, Hex Head M8x16, Zinc	8
32	Vane, Fan	4
33	Roll Pin,ø8*40,	1
34	Roll Pin,ø6*40,	1
35	Pin, Adjustment	1
36	Spreading Disc (Spinner)	1
37	Guard	1
38	Block, Fixing	1
39	Indicator	1
40	Screw Wing, M6x16	1
41	Bolt, Hex Head M10x30, Zinc	4
42	Gearbox,3 hole (complete)	1
43	Bolt, Hex Head M10x110, Zinc	3
44	PTO Assembly(complete)	1
45	Washer,Flat,32mm, Zinc	1
46	Snap Ring,ø38	1
47	Lock Nut,M10	1
48	Washer, Special	4
49	Washer, Nylon, 10mm	1
50	Brace, Right	1